



Maritime Guidance for Distant Source Tsunami Events

Umpqua River, Douglas County, Oregon

Oregon Maritime Tsunami Response Guidance (MTRG) No. 2022-OR-01

Maritime response guidance in this document is based primarily on anticipated effects of a **maximum-considered distant tsunami event** (scenario *AKMax* of the Oregon Department of Geology and Mineral Industries), although general guidance is also given for a much larger tsunami generated by an earthquake on the Cascadia subduction zone (see www.oregontsunami.org for more information on these tsunami scenarios). Smaller distant source tsunamis will occur more frequently and are likely to cause much less damage than the *AKMax* scenario. Check with local authorities for more specific guidance that may be appropriate for smaller distant tsunami events.



Cover Photo: Winchester Bay. Photo Credit: Jonathan Allan, August 2009

INTRODUCTION	3
Tsunami Hazards	6
Relationship between Tsunami Current Speed and Harbor Damage	6
BACKGROUND ON TSUNAMIS	7
NOTABLE HISTORICAL TSUNAMIS	8
Lessons Learned in Northern California from the March 11, 2011, Japanese Tsunami	9
ACTIONABLE TSUNAMI ALERT LEVELS	9
GENERAL GUIDANCE ON RESPONSE TO NOAA ADVISORIES AND WARNINGS	10
UMPQUA RIVER PORT SPECIFIC GUIDANCE	13
ADDITIONAL GUIDANCE	17
Do Your Homework	17
Know real-time and permanent mitigation measures appropriate for your area	17
Land-based Tsunami Evacuation Maps	18
REFERENCES CITED	19
APPENDIX A — ADDITIONAL MAPS	19



Oregon Department
Geology and Mineral
Industries



Oregon Office of
Emergency
Management



Virginia Institute of
Marine Sciences



National Oceanic and
Atmospheric
Administration



Members of the
Oregon Marine
Advisory Council

This project was funded under award #NA20NWS4670064 by the National Oceanic and Atmospheric Administration (NOAA) through the National Tsunami Hazard Mitigation Program and conforms to NTHMP guidance.

DISCLAIMER: The State of Oregon and its partners make no representation or warranties regarding the accuracy of this document and the maps within nor the data from which the maps were derived. Neither the State of Oregon nor its partners shall be liable under any circumstances for any direct, indirect, special, incidental, or consequential damages with respect to any claim by any user or any third party on account of or arising from the use of this document and its maps. In addition, the maritime community is not responsible for the contents of this document.

INTRODUCTION

Tsunamis with the potential to impact the west coast of the United States can be triggered by earthquakes anywhere around the Pacific Rim and will cause sudden water level and current changes for many hours after their first arrival. The location of the earthquake plays an important role in determining the tsunami propagation travel time to the coastal community.

DISTANT TSUNAMIS

These are caused by large subduction zone earthquakes far away from the Oregon coast and will arrive at the mouth of the Umpqua River more than 4 hours after the earthquake. Tsunami waves will cause water level and current changes for many hours after the arrival of the first wave.

The closest distant earthquake source to Oregon is along the eastern Aleutian Islands, Alaska.

Modeled initial wave arrival times (peak wave arrival times in parentheses) for such an

earthquake indicate that the tsunami would reach Winchester Bay (River Mile (RM) 1) in 3 hours 56 minutes (4 hours 2 minutes), 4 hours 14 minutes (6 hours 9 minutes) minutes at The Point (RM7), 4 hours 30 minutes (6 hours 9 minutes) minutes at Gardiner, and 4 hours 26 minutes (6 hours 24 minutes) at Reedsport (RM11). Note that the peak wave is not necessarily associated with the first wave.




Figure 1. The greatest threat to the Oregon coast from a distant tsunami is an earthquake occurring in the eastern Aleutian Islands, Alaska. Tsunamis originating from this source would strike the coast in approximately 4 hours.

LOCAL TSUNAMIS

These are caused by locally generated earthquakes on the Cascadia Subduction Zone (CSZ) immediately offshore the Oregon coast. Local tsunamis will produce catastrophic tsunami waves that will reach the mouth of the Umpqua River in *approximately* 12 minutes (peak wave arrives in 21 minutes) after the start of the earthquake and will flood the Umpqua Estuary in 20 to 50 minutes.

Modeled initial wave arrival times (peak wave arrival times in parentheses) for a CSZ tsunami are 20 (24) minutes at Winchester Bay (RM1), 31 (51) minutes at The Point (RM7), 38 (58) minutes at Gardiner, and 42 (203) minutes at Reedsport (RM11).

This document provides response guidance in the event of a **distant tsunami** for maritime vessels, including commercial fishing vessels and small recreational craft. Review DOGAMI Open-File-Report O-22-07 (Allan and others, 2022) for detailed maritime tsunami guidance on distant and local tsunamis affecting the entire Umpqua estuary. A brief summary of the key actionable responses is provided below for both types of events.





Figure 2. A local CSZ earthquake poses the greatest risk to the Oregon coast. A tsunami triggered here would strike the coast in 10 to 20 minutes.

Distant tsunamis: *You have a minimum of 4 hours after the distant earthquake to take action.* If you are on the water, first check with the U.S. Coast Guard before taking any action. If advised to evacuate to deep water and this option is practical for your vessel and your capabilities to remain offshore for an extended period, **proceed to a staging area greater than 10 fathoms (60 ft) (Figure 3, located ~1 nautical mile west of the Umpqua River mouth).** **Dangerous currents (> 5 knots) are expected to occur at depths shallower than 10 fathoms, and especially within the estuary mouth and navigation channel (orange hazard zone in Figure 3).** If conditions do not permit offshore evacuation, dock your boat and get out of the tsunami evacuation zone.

Local (CSZ) tsunamis: *You have as little as ~12 minutes to take action; plan in advance.* If your boat is docked, you do NOT have time to take your vessel offshore; instead, evacuate by foot to high ground immediately. If you are on the water seaward of the Umpqua River at the time of a local earthquake, **proceed to a staging area greater than 65 fathoms (390 ft) water depth (Figure 3), located ~14.6 nautical miles west of the Umpqua River.** *Safety improves significantly with additional westward travel. The preferred staging area is in depths greater than 100 fathoms (600 ft) located 18 nautical miles west of the Umpqua Estuary).* Sail directly toward the nearest deep water or in a general westward direction. **Dangerous currents (> 5 knots) are expected to occur at depths shallower than 65 fathoms (390 ft; yellow and orange hazard zones in Figure 3).** Note that significant wave heights may be greatly amplified by strong opposing tsunami currents.

Figure 3. Offshore maritime staging areas for the Umpqua River area. Map identifies the minimum water depths to the distant (>10 fathoms) and local (>65 fathoms) maritime tsunami staging areas offshore the coast. Note: bathymetric contours on the map are fathoms (1 fathom = 6 ft); shaded regions define areas subject to dangerous current velocities.



Tsunami Hazards

Tsunami wave impacts are greatest in and around ocean beaches, low-lying coastal areas, and bounded water bodies such as harbors and estuaries. These areas should always be avoided during tsunami events. Any tsunami event can threaten harbors, facilities, and vessels.

Tsunami hazards that can directly affect boats/boaters include:

- Sudden water-level fluctuations, which could result in:
 - docks overtopping piles as water levels rise; and
 - grounding of boats and docks as water levels drop.
- strong and unpredictable currents, especially where there are narrow openings/parts of harbor;
- tsunami bores and amplified waves resulting in swamping of boats and damage to docks;
- eddies/whirlpools causing boats to lose control;
- drag on deep draught ships causing damaging forces to vessels tied to docks; and
- collision with other vessels, docks, and debris in the water.

Dangerous tsunami conditions can last tens of hours after first wave arrival, causing problems for inexperienced and unprepared boaters who take their boats offshore.

Relationship between Tsunami Current Speed and Harbor Damage

Analysis of recent tsunami impacts indicates a relationship between current speed and harbor damage. The Damage Index (from Lynett and others, 2013) to the right has been used to determine their relationship with simulated tsunami current velocities (see color codes here for green, yellow, orange, and red areas and on the maps showing tsunami current thresholds ([Figure 4](#), p4 and Appendix A tsunami current maps)):

CURRENTS = DAMAGE

0-3 knots = No Damage

3-6 knots = Minor/Moderate Damage

6-9 knots = Moderate/Major Damage

>9 knots = Major/Complete Damage

Damage Index	Damage Type
0	No damage
1	Small buoys moved
2	1-2 docks/small boats damaged, large buoys moved
3	Moderate dock/boat damage, mid-sized vessels off moorings
4	Major dock/boat damage, large vessels off moorings
5	Complete destruction

BACKGROUND ON TSUNAMIS

Very large underwater earthquakes are the most common cause of tsunami waves, which can result in significant damage at very distant shores. Earthquake-caused tsunami waves occur when the seafloor abruptly deforms and vertically displaces (lifts) the overlying water column. The displaced water travels outward in a series of waves that grow in height as they encounter shallower water along coastlines. Tsunami wave impacts are greatest in and around ocean beaches, low-lying coastal areas, and bounded water bodies such as harbors and estuaries. Potential tsunami wave impact areas should always be avoided during tsunami events.

Any tsunami event can threaten harbors, facilities, and vessels. Unlike a local tsunami, which requires the public to evacuate immediately to high ground (or to deep water if out on the ocean), a distant tsunami does allow at least some time for local agencies and citizens to take steps to help reduce the expected impacts of tsunami surges. However, the time available for response is minimal and may not be sufficient for completing all needed mitigation actions. Therefore, the actions to be taken must be prioritized and based on life-safety preservation.

The source location of a distant tsunami greatly impacts the ability of local governments to respond and the public to mitigate expected impacts. A tsunami originating in *Chile (14–15 hours away)* or *Japan (9–10 hours away)* will allow much more local mitigation activity than will a tsunami originating in the *Gulf of Alaska or the Aleutian Islands (3.5–5 hours away)*. Of these, the eastern Aleutian Islands represent the closest distant earthquake source to the Oregon coast (~4 hours for the waves to arrive at the mouth of the Umpqua estuary).

Response entities and the public should allow enough time to complete the necessary steps to prepare for a distant tsunami. For example, if you are on the water, first check with the U.S. Coast Guard before taking any action. If advised to evacuate to deep water and this option is practical for your vessel and you are capable of remaining offshore for an extended time period, proceed to a staging area **greater than 10 fathoms (60 ft)** (*dashed orange line in Figure 3, ~1 nautical mile west of the Umpqua River mouth*). If conditions do not permit maritime evacuation, dock your boat and evacuate out of the orange hazard zone located on the [Detailed tsunami evacuation zone maps](#) for Reedsport, **Gardiner and Winchester Bay**; links to various community tsunami evacuation maps are provided on page 18 of this guidance document. Be aware that local mitigation activities will be extensive and could involve large numbers of people, resulting in congestion and delayed actions. It may not be possible to complete normally simple mitigation actions in the time frame available.

NOTABLE HISTORICAL TSUNAMIS

Table 1 provides basic information about historical tsunami events either observed (e.g., near Winchester Bay) or measured at the Charleston tide gauge on the south-central Oregon coast; some additional minor tsunamis are not included. According to NGDC (2017) there are effectively two types of observations:

1. Water heights as observed (estimated) by an eyewitness (i.e., the maximum elevation of the wave), and
2. Measurements from a tide gauge, with the measured tsunami water level expressed as a *wave amplitude*, which is half the height of the tsunami wave.

The largest, most damaging distant-source tsunamis to affect the Umpqua estuary have come from large earthquakes in the Alaska-Aleutian Islands region (1964) and most recently from Japan (2011) (**Table 1**). The peak wave amplitude and damage information provided in **Table 1** may help guide port authorities in their decision making when responding to future Advisory and Warning level tsunamis in the area. For example, the 1964 Alaska tsunami provides a threshold, since damage was reported for Winchester Bay for an estimated tsunami water level of 4.2 m (14 ft), occurring on a higher tide.

Table 1. Historical tsunami events observed (e.g., Winchester Bay) or measured (Charleston, Coos Bay) on the south-central Oregon coast since 1964 (NGDC, 2017). Bold rows highlight the effects of the 1964 event that resulted in some damage, versus other events that produced small to negligible tsunami waves.

Location	Event	Peak Amplitude Observed		NTWC Tsunami Alert Level Assigned	Tides During First 5 Hours	Damage Summary
		(m)	(ft)			
Umpqua River	1964 M9.2 Alaska	1.7	5.6	Warning	High*	damage reported
Winchester Bay	1964 M9.2 Alaska			—	High*	damage to docks
Charleston	2006 M8.3 Kuril	0.19	0.6	—	Low	no damage reported
Charleston	2009 M8.0 Samoa	0.13	0.4	Advisory**	High	no damage reported
Charleston	2010 M8.8 Chile	0.16	0.5	Advisory**	Low	no damage reported
Charleston	2011 M9.0 Japan	0.71	2.3	Warning**	Low	no damage reported
Charleston	2012 M7.7 Canada	0.13	0.4	Information	High	no damage reported
Charleston	2022 Hunga Tonga volcanic eruption	0.25	0.8	Advisory**	High	no damage reported

*Alaska 1964 arrival on PNW coast was at mean high water flood tide.

**Alert assigned by forecast outside of bay.

Lessons Learned in Northern California from the March 11, 2011, Japanese Tsunami

During the March 11, 2011, event, nearly two-thirds of the fishing boats in Crescent City Harbor headed to sea (Wilson and others, 2013). Many were prepared and practiced evacuation from the harbor prior to the event. Once the tsunami hit and operators realized they were unable to return to Crescent City Harbor, decisions had to be made as to where to go because of a huge storm approaching the coast. Some vessels had enough fuel to make it to Brookings Harbor, Oregon or to Humboldt Bay, California. Some smaller vessels did not have enough fuel and made the choice to re-enter Crescent City Harbor to anchor. Some Crescent City captains had never been to Humboldt Bay and some were running single handed as they did not have enough time to round up crewmen. As with captains who chose to go to Brookings, captains headed to Humboldt Bay kept in close contact with each other for safety and moral support. Even though the tsunami initially impacted the west coast on the morning of March 11, 2011, the largest surges in Crescent City did not arrive until later in the evening. In summary, the lessons learned include:

1. It is recommended that harbors and vessels practice their offshore evacuation plan.
2. If evacuating to deep water, operators should ensure that their vessels are equipped to handle both the existing and forecast ocean conditions and have sufficient fuel and supplies to remain offshore for several days.
3. Recognize that the port of departure may have been damaged by the tsunami, such that vessel operators may not be able to return to the same port.
4. The largest surges may not arrive until much later.

ACTIONABLE TSUNAMI ALERT LEVELS

Tsunami Advisories and Warnings are the two actionable alert levels for maritime communities.

For both Advisory and Warning level events, it is important that clear and consistent directions are provided to the entire boating community and to waterfront businesses. Sign up to receive notifications from the National Tsunami Warning Center in Palmer, Alaska

(<https://ntwc.ncep.noaa.gov/?page=productRetrieval>); the same alerts are also provided via the NANOOS TsunamiEvac application, (http://www.nanoos.org/mobile/tsunami_evac_app.php), which issues two types of bulletins that require action by Oregon boaters:



Tsunami Advisories

Peak tsunami wave heights of 1 to 3 feet are expected, indicating strong and dangerous currents can be produced in harbors near the open coast.

- **SIGNIFICANT** tsunami currents or damage are possible **in the Umpqua estuary** near the Winchester Bay harbor entrances or narrow constrictions.



Tsunami Warnings

Tsunami wave heights could exceed 3 feet in harbors near the open coast, indicating very strong, dangerous currents and inundation of dry land is anticipated.

- **SIGNIFICANT** tsunami currents or damage are possible **in the Umpqua estuary** near the Winchester Bay harbor entrances or narrow constrictions.
- Depending on the size of the tsunami and the tidal conditions, **docks may overtop the pilings.**

GENERAL GUIDANCE ON RESPONSE TO NOAA ADVISORIES AND WARNINGS

In and near Umpqua estuary



Tsunami Advisories

- **During the distant event** (before the tsunami arrives):
 - Evacuate from all structures and vessels in the water.
 - Public access to waterfront areas will be limited by local authorities.
 - All personnel working on or near the water should wear personal flotation devices.
 - Port authorities will shut off fuel to fuel docks, and all electrical and water services to all docks.
 - Secure and strengthen all mooring lines throughout the harbor, specifically areas near the entrance or narrow constrictions.
 - If you are on the water:
 - Check with the U.S. Coast Guard (USCG) before taking any action.
 - Monitor VHF FM Channel 16 and the marine WX channels for periodic updates of tsunami and general weather conditions; additional information will be available from NOAA Weather Radio.
 - If advised that offshore evacuation is an option and this is practical for your vessel and you are capable of staying offshore for an extended time period, **proceed to depths greater than 10 fathoms (60 ft).**
 - **For the Umpqua River estuary, including Winchester Bay, evacuate from the orange hazard zone (Figure 3) and head to depths greater than 10 fathoms, located ~1 nautical mile west of the mouth of the Umpqua River.**

- If located in Reedsport, offshore evacuation is not necessary. Mariners should, however, consider further safeguarding their vessel by adding additional mooring lines.
- **After the event:** Port authorities will not allow the public to re-enter structures and vessels in the water until the Advisory is cancelled.



Tsunami Warnings

- **During the distant event** (before the tsunami arrives):
 - Public access to waterfront areas will be limited by local authorities.
 - Port authorities will shut off fuel to fuel docks, and all electrical and water services to all docks.
 - If you are on the water:
 - Check with the U.S. Coast Guard (USCG) before taking any action.
 - Monitor VHF FM Channel 16 and the marine WX channels for periodic updates of tsunami and general weather conditions; additional information will be available from NOAA Weather Radio.
 - If advised that offshore evacuation is an option and this option looks practical for your vessel and you are capable of staying offshore for an extended time period, **proceed to depths greater than 10 fathoms (60 ft).**
 - **For the Umpqua River estuary, including Winchester Bay, evacuate from the orange hazard zone (Figure 3) and head to depths greater than 10 fathoms, located ~1 nautical mile west of the mouth of the Umpqua River.**
 - If located in Reedsport, offshore evacuation is not necessary. Mariners should, however, consider further safeguarding their vessel by adding additional mooring lines.
 - If conditions do not permit marine evacuation, dock your boat and get out of the distant tsunami evacuation zone (orange hazard zone on the [Detailed tsunami evacuation zone maps](#) for Reedsport, ***Gardiner and Winchester Bay*** ; links to various community tsunami evacuation maps are provided on page **18** of this guidance document).
 - Vessels considering leaving the harbor and heading to sea, please consider the following:
 - Make sure your family is safe first.
 - Check tide, bar, and ocean conditions.
 - Check the weather forecast for the next couple of days.
 - Ensure you have enough fuel, food, and water to last a couple of days.
 - Have someone drive you to the marina so your vehicle is not in the DISTANT Tsunami Evacuation Zone (ORANGE zone on the [Detailed tsunami evacuation zone maps](#) for Reedsport, ***Gardiner and Winchester Bay*** ; links to various community tsunami evacuation maps are provided on page **18** of this guidance document).

- PLEASE REMEMBER: There may be road congestion. There may also be vessel congestion in the harbor as ships, barges, and other vessels attempt to depart at the same time. All vessels should monitor VHF Channel 16 and use extreme caution. NEVER impede another vessel.
 - If you do not have time to accomplish your preparation activities, you should not make the attempt.
 - Vessels that remain in port should check with local port authorities for guidance on what is practical or necessary with respect to vessel removal or mooring options, given the latest information on the distant tsunami event; then evacuate to an area outside of the distant tsunami evacuation zone (orange hazard zone on the [Detailed tsunami evacuation zone maps](#) for Reedsport, ***Gardiner and Winchester Bay*** ; links to various community tsunami evacuation maps are provided on page **18** of this guidance document).
- **After the event:**
 - The "CAUTIONARY RE-ENTRY" message DOES NOT MEAN THAT THE HARBOR IS OPEN. It is for land entry only.
 - Mariners at sea should stay at sea until after the United States Coast Guard has issued a message stating that the port is open for traffic.
 - Check with your docking facility to determine its ability to receive vessels. Adverse tsunami surge impacts may preclude safe use of the harbor. Vessels may be forced to anchor offshore or to travel great distances to seek safe harbor.
 - An extended stay at sea is a possibility if the harbor is impacted by debris or shoaling. Make sure your vessel is prepared to stay at sea. Where possible, mariners should congregate for mutual support while at sea, at anchor, or during transit elsewhere.
 - If in an onshore assembly or evacuation area, check with local authorities for guidance before returning to the inundation zone.

UMPQUA RIVER PORT SPECIFIC GUIDANCE

Figure 4 presents a map of the (*top*) maximum water levels and (*bottom*) tsunami current velocities and expected port damage resulting from a maximum-considered distant tsunami initiating near the eastern Aleutian Islands (Allan and others, 2022). More detailed maps specific to Winchester Bay and Reedsport are included at the end of this report on page [18](#).

Tsunami modeling completed by Allan and others (2022) indicates that the highest tsunami water levels are observed along the open coast, especially offshore the North Spit. Dangerous conditions are also observed at the mouth of the Umpqua River, within Winchester Bay marina, and in the navigation channel downstream of RM4.

Modeled tsunami currents indicate potentially dangerous currents across much of the lower estuary (downriver of RM5). Strong currents exceeding 9 knots (red color, **Figure 4** bottom) are expected to occur between the jetties at the mouth of the estuary. Strong currents in the 6-9 knot range (orange color) are expected in the navigation channel near the mouth, adjacent to Halfmoon Bay, and within the Winchester Bay marina (**Figure 4, bottom**). Of major concern will be the interaction of incoming tsunami waves with opposing currents generated during an ebb or ebb slack tide coupled with seaward directed tsunami drainage, which will likely contribute to the amplification of waves occurring near the mouth (see Appendix A).

Within the estuary, the model results indicate that much of the lower estuary between RM1 and RM4 would be affected by currents in the 3–6 knot range (yellow color, **Figure 4, bottom**). Currents of this magnitude are likely to cause moderate damage to facilities located adjacent to the Winchester Bay marina. For vessels moored in the harbor, currents of this magnitude could result in significant damage to the boats, including boats breaking their mooring lines and colliding with other vessels. For vessels moored at Reedsport in the upper estuary and elsewhere, modeling completed by Allan and others (2022) indicates that an AKMax tsunami event would not significantly impact those areas. However, operators may be advised to add additional mooring lines and/or drag anchors to help stabilize larger vessels.

Maritime tsunami evacuation upriver toward Reedsport (upper estuary) or offshore to the distant staging area may be feasible for some smaller boats and vessels. For vessels evacuating from Winchester Bay, evacuate from the orange hazard zone (Figure 3**) and head to depths greater than 10 fathoms, located ~1 nautical mile west of the mouth of the Umpqua River.**

Maritime evacuation will depend on how long it takes for a vessel to get underway (a conservative estimate is about 1 hour for larger vessels), the speed at which a vessel can travel, and offshore marine conditions. For example, the distance from Winchester Bay to Reedsport (where tsunami currents fall below 3 knots) is 9.8 nautical miles (**Table 2**). For a vessel traveling at 6 knots, this equals ~1 hour 38 minutes travel time. Offshore evacuation is not necessary for vessels moored at Reedsport in the upper estuary. Offshore evacuation assumes that conditions at the estuary mouth are manageable for vessels trying to move out through the mouth into the Pacific Ocean.

Table 2. Maritime evacuation times to nearest offshore and upriver staging destinations. Evacuation times assume an average vessel speed of 6 knots. (NM = Nautical Miles)

Location	Distance to Offshore		Distance to Upriver	
	Staging (NM)	Time to Safety	Staging (NM)	Time to Safety
Winchester Bay	2.7	27 min	9.8	1 hour 38 min
The Point	7.3	1 hour 13 min	3.5	35 min
Reedsport	10.8	1 hour 48 min	NA	NA

Strong current velocities are expected at the entrance to the Winchester Bay marina, and around the docks.

Besides powerful currents, the navigation channel, ports, marinas, and docks may also be susceptible to the occurrence of whirlpools and gyres (Figure 5, top). Strong currents and vorticity will be especially significant at entrances to the Winchester Bay marina (see Winchester Bay maps in appendix). Rise of water above prevailing tide is expected to be +8 ft above the tide within the Winchester Bay marina (Figure 4, top), +3 ft at The Point, decreasing to +2 ft at Reedsport in the upper estuary. Floating dock pilings should therefore be constructed to handle this change in water level plus an appropriate tide such as Mean Higher High Water (MHHW). MHHW is 8.3 ft above geodetic mean sea level (NAVD88) in this area.

Dangerous tsunami currents are expected to persist for at least 4 hours after the initial wave arrival.

Tsunamis may be characterized by multiple surges of water lasting at least several hours. Withdrawing tsunami waves (Figure 5, bottom, red/brown colors; gray color indicates complete exposure of the bed) will rapidly drain the estuary and can ground vessels, making them vulnerable to being sunk by the next tsunami surge. This is likely to be an issue over large parts of the estuary, while grounding in the navigation channel is unlikely to occur.

Wind waves can be significantly amplified due to the occurrence of opposing currents.

Besides the occurrence of strong currents at the mouth of the Umpqua Estuary, strong currents may be felt out on the ocean. Model simulations in the vicinity of the Umpqua River indicate that dangerous currents will be especially significant up to 1 nautical mile west of the mouth (Figure 4, bottom), with strong currents persisting for several hours after the first wave arrives. Wind waves may also be amplified, especially on the tsunami outgoing (ebb) flow (Appendix A). For example, a 5-ft wave could be amplified 12–30% by a 3-knot opposing current generated by a tsunami, and by as much as 95% as currents approach 6 knots. If using existing single-point moorings or when anchoring, be aware that the dead-man or anchor could move or the mooring lines or chains could break because of strong or changing currents. Initial evaluations and some field observations of anchor stability indicate that currents greater than 3-4 knots will move a dead-man or anchor.

Figure 4. Model results of the maximum tsunami (top) water levels and (bottom) currents generated by a distant earthquake and tsunami (AKMax) occurring in the eastern Aleutian Islands, Alaska. Time histories of water levels and currents are provided in Appendix A for RM-1 (mouth), RM1 (Winchester Bay), RM7 (The Point), and RM11 (Reedsport).





Figure 5. Ensemble model results of the (top) maximum vorticity and (bottom) minimum water depths generated by a distant earthquake and tsunami (AKMax) occurring in the eastern Aleutian Islands, Alaska. The top plot is a measure of the potential for rotation (gyres and whirlpools – hot colors indicate strong potential), while the bottom shows the expected minimum water depths from tsunamis.



ADDITIONAL GUIDANCE

Do Your Homework

Check the DOGAMI Tsunami Clearinghouse (<http://www.oregontsunami.org>) for detailed information on tsunami hazards in your area and tips on preparedness. Preparedness information is also available from Oregon Emergency Management (<https://www.oregon.gov/OEM/hazardsprep/Pages/Tsunami.aspx>). Download and review the statewide tsunami maritime guidance brochure (<https://www.oregongeology.org/pubs/tsubrochures/TsunamiBrochureMaritime.pdf>). For general information on tsunami maritime hazards consult <https://www.tsunami.noaa.gov/> and the information below.

Know real-time and permanent mitigation measures appropriate for your area

This information can be used to identify real-time response mitigation measures, determine where infrastructure enhancements should be initiated, and provide a mechanism for pre-disaster hazard mitigation funding through additions to local hazard mitigation plans. Although these products, plans, and related mitigation efforts will not eliminate all casualties and damages from future tsunamis, they will provide a basis for reducing future impacts on life-safety, infrastructure, and recovery in Oregon maritime communities.

Real-Time Response Mitigation Measures

- Move boats and ships out of harbors
- Reposition ships within harbor
- Move large, deep draft ships from harbor entrances
- Remove small boats/assets from water
- Shut down infrastructure before tsunami arrives
- Evacuate public/vehicles from water-front areas
- Restrict boats from moving during tsunami
- Prevent boats from entering harbor during event
- Secure boat/ship moorings
- Personal flotation devices/vests for harbor staff
- Move hazardous materials away from water
- Move buoyant assets away from water
- Stage emergency equipment outside affected area
- Activate Mutual Aid System as necessary
- Activate Incident Command at evacuation sites
- Alert key first responders at local level
- Aid traffic evacuating harbor
- Personnel to assist rescue, survey, and salvage
- Identify boat owners/live-aboards; establish phone tree, or other notification processes

Permanent Mitigation measures

- Fortify and armor breakwaters
- Increase size and stability of dock piles
- Strengthen cleats and single-point moorings
- Improve floatation portions of docks
- Increase flexibility of interconnected docks
- Improve movement along dock/pile connections
- Increase height of piles to prevent overtopping
- Deepen/dredge channels near high hazard zones
- Move docks/assets away from high hazard zones
- Reduce exposure of petroleum/chemical facilities
- Strengthen boat/ship moorings
- Construct floodgates
- Prevent uplift of wharfs by stabilizing platform
- Add debris deflection booms to protect docks
- Make harbor control structures tsunami resistant
- Construct breakwaters farther away from harbor
- Install tsunami warning signs
- Strengthen equipment/assets (patrol/tug/fireboats, cranes, etc.) to assist emergency response activities

Land-based Tsunami Evacuation Maps

Consult your local community tsunami evacuation resources

For land-based tsunami evacuation guidance, use existing tsunami evacuation maps provided on the Oregon Tsunami Clearinghouse (<http://www.oregontsunami.org>) to determine an evacuation location safe from a distant (orange zone) or local (yellow zone) tsunami.

Detailed tsunami evacuation zone maps for Reedsport, Gardiner and Winchester Bay can be found online at:

- PDF: <https://www.oregongeology.org/tsuclearinghouse/pubs-evacbro.htm>
- Interactive web portal map: <http://nvs.nanoos.org/TsunamiEvac>

Regional maps covering Winchester Bay, South Umpqua River Jetty, Gardiner, and Reedsport may be found at:

- https://www.oregongeology.org/pubs/tsubrochures/Reedsport_EvacBrochure_onscreen.pdf
- https://www.oregongeology.org/tsuclearinghouse/pubs-evacbro_neighborhoods.htm#Douglas

Smartphone app:

- http://www.nanoos.org/mobile/tsunami_evac_app.php

Warning: After an earthquake and tsunami, cell phone towers might be damaged.

Know and practice your evacuation plan beforehand.

Additional Resources:

Oregon Tsunami Clearinghouse: <http://www.oregontsunami.org>

Oregon Emergency Management: <https://www.oregon.gov/OEM/>

Oregon Statewide Maritime Evacuation Guidance brochure:

<https://www.oregongeology.org/pubs/tsubrochures/TsunamiBrochureMaritime.pdf>

Document adapted from the Humboldt Bay Tsunami Maritime Actions website:

(<http://humboldtharborsafety.org/sites/humboldtharborsafety.org/files/BMP%20Tsunami%20Maritime%20Actions%20Small%20Craft%20Final.pdf>).

REFERENCES CITED


- Allan, J.C., Priest, G.R., Zhang, Y. J., and Gabel, L., 2018, Maritime tsunami evacuation guidelines for the Pacific Northwest coast of Oregon: Natural Hazards, v. 94, no. 1, p. 21–52. <https://doi.org/10.1007/s11069-018-3372-2>
- Allan, J.C., Zhang, J., O'Brien, F., Gabel, L., 2022, Umpqua River tsunami modeling: Toward improved maritime planning response: Oregon Department of Geology and Mineral Industries Open-File Report O-22-07, 76 p. <https://www.oregongeology.org/pubs/ofr/p-O-20-08.htm>
- Lynett, P.J., Borrero, J., Son, S., Wilson, R., and Miller, K., 2013, Assessment of the tsunami-induced current hazards: Geophysical Research Letters, v. 41, no. 6, 2048-2055. <https://doi.org/10.1002/2013GL058680>
- National Geophysical Data Center [NGDC]/World Data Service, 2017, NCEI/WDS Global Historical Tsunami Database. NOAA National Centers for Environmental Information. <https://doi.org/10.7289/v5pn93h7> [accessed June 2017]
- Wilson, R.I., Admire, A.R., Borrero, J.C., Dengler, L.A., Legg, M.R., Lynett, P., McCrink, T.P., Miller, K.M., Ritchie, A., Sterling, K., 2013. Observations and impacts from the 2010 Chilean and 2011 Japanese tsunamis in California (USA). Pure and Applied Geophysics, 170 (6-8): p. 1127-1147

APPENDIX A — ADDITIONAL MAPS

Unless otherwise indicated, maps on the following pages are from Allan and others (2020):

- Plot showing change in wave amplitudes based on opposing currents
- Tsunami wave arrival times for an eastern Aleutian Islands (**DISTANT**) earthquake and tsunami
- Maximum water levels and currents at the Winchester Bay marina
- Vorticity and minimum water depths at the Winchester Bay marina
- Maximum water levels and currents at Reedsport
- Vorticity and minimum water depths at Reedsport
- Time histories of water levels for the Umpqua River mouth, near Winchester Bay marina, The Point, and for Reedsport for an AKMax **DISTANT** tsunami
- Time histories of tsunami currents for the Umpqua River mouth, near Winchester Bay marina, The Point, and for Reedsport for an AKMax **DISTANT** tsunami

Wave amplification estimate. Plot shows change in wave amplitudes based on opposing currents (from Allan others, 2018):



How to use:


Step 1. Identify the prevailing peak wave period defined for the x-axis.

Step 2. Determine the outgoing (opposing) current velocity (knots).

Step 3. From steps 1 and 2, identify on the y-axis the calculated percentage increase in wave height.

Example: A peak period of 16 sec will yield a 12% (60%) increase in the wave height with a 3 (9) knot opposing current.


Tsunami wave arrival times defined for AKMax (*DISTANT*) for discrete locations along the Umpqua River estuary. Times reported are in minutes and are relative to the initial (3 hr 50 min) wave arrival at the mouth of the Umpqua River. Red numbers correspond to the initial wave arrival (the point at which the water level begins to depart from normal), while the bold, black number reflects the time at which the maximum wave arrives.






Maritime Guidance for Distant Source Tsunami Events


Winchester Bay Marina: Maximum water levels (*top*) and tsunami current velocities (*bottom*) from a distant tsunami initiating near the eastern Aleutian Islands (AKMax).




Winchester Bay Marina: Map of the maximum vorticity (*top*) and minimum water depths (*bottom*) generated by a distant tsunami initiating near the eastern Aleutian Islands (AKMax). The top plot is a measure of the potential for rotation (hot colors = strong potential for gyre and whirlpool development), while the bottom plot shows the expected minimum water depths from the tsunamis.




Reedsport: Maximum water levels (*top*) and tsunami current velocities and expected port damage (*bottom*) resulting from a distant tsunami initiating near the eastern Aleutian Islands (AKMax).



Reedsport: Map of the maximum vorticity (*top*) and minimum water depths (*bottom*) generated by a distant tsunami initiating near the eastern Aleutian Islands (AKMax). The top plot is a measure of the potential for rotation (hot colors = strong potential for gyre and whirlpool development), while the bottom plot shows the expected minimum water depths from the tsunamis.



Time histories of tsunami waves and water levels for select sites (top to bottom: Umpqua River mouth (RM-1), near Winchester Bay marina (RM1), The Point (RM7), and for Reedsport (RM11)) resulting from a distant tsunami (AKMax) initiating near the eastern Aleutian Islands, Alaska. Simulations shown include both a flood and ebb tide condition. Gray shading defines the envelope of variability of tsunami water levels from a suite of simulations.



Time histories of tsunami current velocities for select sites (top to bottom: Umpqua River mouth (RM-1), near Winchester Bay marina (RM1), The Point (RM7), and for Reedsport (RM11) resulting from a distant tsunami (AKMax) initiating near the eastern Aleutian Islands, Alaska. Simulations shown include both a flood and ebb tide condition. Gray shading defines the envelope of variability of tsunami current velocities from all simulations.

